

## 3G card Compatibility List

資料更新日期: 2010/02/01

ID	Card Vendor	Model No.	Interface Type	備註
1	AIKO	81D	USB	
2	AIKO	82D	USB	
3	Alcatel	X060	USB	
4	Alcatel	X200	USB	
5	Amoi	V870	USB	
6	Anugrahpratama	Growell GW-1033C	PC Card	
7	AnyData	ADU-500A	USB	
8	AnyData	APE-540H	ExpressCard	
9	APBW	WH200 II	USB	
10	ASUS	T500	ExpressCard	
11	AT&T	QuickSilver	USB	
12	BandRich	BandLuxe C-100	ExpressCard	
13	BandRich	BandLuxe C-120	USB	
14	BandRich	BandLuxe C-170	USB	
15	BandRich	BandLuxe C-270	USB	
16	BES	WM61	USB	
17	C-Motech	CGU-628A	USB	
18	C-Motech	CGU-629	USB	
19	C-Motech	CGU-629C	USB	
20	C-Motech	CHU-629S	USB	
21	C-Motech	XS Stick W12	USB	
22	C-Motech	XS Stick W14	USB	
23	C-Motech	CCU-550	USB	
24	C-Motech	CDC-650	PC Card	
25	C-Motech	U680	USB	
26	C-Motech	CBU-410S	USB	
27	Cricket	A600	USB	
28	Datang	AirCard901	USB	
29	Datang	DTM5731E	USB	
30	D-Link	DWM-151	USB	
31	D-Link	DWM-152	USB	
32	D-Link	DWM-156	USB	
33	D-Link	DWM-162-U5	USB	
34	EpiValley	Model 220	USB	
35	EpiValley	SEC-7089	USB	
36	ESTON	EST-611P	PC Card	
37	ESTON	EST-618U	USB	
38	ESTON	EST-638U	USB	
39	ESTON	501P	PC Card	
40	E-TEL	ET230U	USB	

41	Fly Card	FLY-HU1	USB	
42	Franklin	CGU-628A	USB	
43	Franklin	CGU-629	USB	
44	Franklin	CDU-550	USB	
45	Franklin	CDU680	USB	
46	Giant	D301	USB	
47	Gigabyte	GSMART MD800	ExpressCard	
48	Growell	C803	PC Card	
49	Haier	EM100	USB	
50	Haier	WM100	USB	
51	Haier	WM200	USB	
52	Haier	WM500	USB	
53	Haier	CE100	USB	
54	Haier	CM200	USB	
55	Haier	HT-DM300	USB	
56	Hisense	E6801	USB	
57	Hojy	733	USB	
58	Hojy	TD368	USB	
59	Honest	UC128	USB	
60	Huawei	D01HW	USB	
61	Huawei	D02HW	USB	
62	Huawei	D12HW	USB	
63	Huawei	D21HW	USB	
64	Huawei	D22HW	USB	
65	Huawei	D23HW	USB	
66	Huawei	D31HW	USB	
67	Huawei	E1152	USB	
68	Huawei	E1550	USB	
69	Huawei	E156G	USB	
70	Huawei	E160	USB	
71	Huawei	E160G	USB	
72	Huawei	E161	USB	
73	Huawei	E169	USB	
74	Huawei	E169U	USB	
75	Huawei	E170	USB	
76	Huawei	E172	USB	
77	Huawei	E1750	USB	
78	Huawei	E1762	USB	
79	Huawei	E180	USB	
80	Huawei	E1820	USB	
81	Huawei	E182E	USB	
82	Huawei	E220	USB	
83	Huawei	E226	USB	
84	Huawei	E230	PC Card	

85	Huawei	E270	USB	
86	Huawei	E510	USB	
87	Huawei	E600	PC Card	
88	Huawei	E612	PC Card	
89	Huawei	E620	PC Card	
90	Huawei	E660A	PC Card	
91	Huawei	E800	PC Card	
92	Huawei	K3520	USB	
93	Huawei	K3715	USB	
94	Huawei	K3765	USB	
95	Huawei	E1260	USB	
96	Huawei	EC122	USB	
97	Huawei	ec1260	USB	
98	Huawei	EC1261	USB	
99	Huawei	EC168	USB	
100	Huawei	EC169	USB	
101	Huawei	EC189	USB	
102	Huawei	EC226	USB	
103	Huawei	EC228	USB	
104	Huawei	EC360	PC Card	
105	Huawei	ET128	USB	
106	IPWireless	IPWireless_V1	PC Card	
107	IPWireless	IPWireless_V3	PC Card	
108	IPWireless	IP wireless V2	PC Card	
109	ITON	ITON530C	PC Card	
110	IUSACELL	PC5740	PC Card	
111	KPT	WM66	USB	
112	Kyocera	KPC650	PC Card	
113	Kyocera	1.9G AS	PC Card	
114	Kyocera	IBurst PC card	PC Card	
115	Kyocera	UTC1780DMY-A	PC Card	
116	Kyocera	UTU1900D	USB	
117	Lenovo	SPRD-8800	USB	
118	LightSpeed	EDGE-100M	PC Card	
119	LightSpeed	EDGE-100N	PC Card	
120	LightSpeed	EDGE-180M	USB	
121	LightSpeed	GPRS-100S	PC Card	
122	LightSpeed	HSDPA-180C	USB	
123	Long Cheer	71_11	USB	
124	Long Cheer	C01LC	USB	
125	Long Cheer	D11LC	USB	
126	Long Cheer	D12LC	USB	
127	Long Cheer	D21LC	USB	
128	Matrix	MTX-H25	USB	

129	Maxon	USB3-8521	USB	
130	MLW Telecom	SU-8100U	USB	
131	MLW Telecom	SU-8200	USB	
132	MLW Telecom	SU-8500U	USB	
133	MLW Telecom	SU-8600U	USB	
134	MLW Telecom	SU-9000U	USB	
135	MLW Telecom	SU-6200	USB	
136	NEC	D01NE	PC Card	
137	NOKIA	CS-10	USB	
138	NOKIA	CS-15	USB	
139	Novatel	MC930D	USB	
140	Novatel	MC935D	USB	
141	Novatel	MC950D	USB	
142	Novatel	MC990D	USB	
143	Novatel	NRM-XU870	ExpressCard	
144	Novatel	U530	PC Card	
145	Novatel	U730	PC Card	
146	Novatel	U740	PC Card	
147	Novatel	X950D	ExpressCard	
148	Novatel	ES720	USB	
149	Novatel	MC727	USB	
150	Novatel	MC760	USB	
151	Novatel	U720	USB	
152	Novatel	U727	USB	
153	Novatel	U760	USB	
154	ONDA	DT515HS	USB	
155	Onda	MSA405HS	USB	
156	ONDA	MSA501HS		
157	Option	GE0201	ExpressCard	
158	Option	GI0322	USB	
159	Option	Globe Trotter	ExpressCard	
160	Option	GT EXPRESS 7.2	ExpressCard	
161	Option	GT MAX	PC Card	
162	Option	GTM378(GI0201)	USB	
163	Option	GTM382	USB	
164	Option	GX0201	PC Card	
165	Option	GX0202	PC Card	
166	Option	HSUPA-380P	USB	
167	Option	ICON 225	USB	
168	Option	ICON 401	USB	
169	Option	ICON 431	USB	
170	Option	iCon 515	USB	
171	Option	iCon031	USB	
172	Option	iCon451	USB	

173	Option	iCon452	USB	
174	Option	iCon505	USB	
175	Pantech	PX-500	PC Card	
176	Pantech	UM150	USB	
177	Pantech	UM175	USB	
178	Pin Su	EU930	USB	
179	Prolink	PHS100	USB	
180	Prolink	PHS300	USB	
181	Promate	E-GO3	USB	
182	Qsida	Flying Beet(H21)	USB	
183	Quanta Computer	GKD	USB	
184	Quanta Computer	GQR	USB	
185	Quanta Computer	MU-Q101	USB	
186	Quanta Computer	Q110	USB	
187	QuickTel	HM405	USB	
188	Samsung	SGH-H128	USB	
189	SHber	H951	USB	
190	SHber	H955	USB	
191	SHber	H956	USB	
192	SHber	E750	USB	
193	SHber	E751	USB	
194	SHber	E751+	USB	
195	SHber	E752	USB	
196	SHber	E753+	USB	
197	Sierra Wireless	875U	USB	
198	Sierra Wireless	AC501	ExpressCard	
199	Sierra Wireless	AC775	PC Card	
200	Sierra Wireless	AC880E	ExpressCard	
201	Sierra Wireless	AC881U	USB	
202	Sierra Wireless	AC885	USB	
203	Sierra Wireless	AirCard 850	PC Card	
204	Sierra Wireless	AirCard 875	PC Card	
205	Sierra Wireless	AirCard 880	PC Card	
206	Sierra Wireless	AirCard 881	PC Card	
207	Sierra Wireless	Compass 885U	USB	
208	Sierra Wireless	Compass 888_889	USB	
209	Sierra Wireless	USB306/USB307	USB	
210	Sierra Wireless	595U	USB	
211	Sierra Wireless	598U	USB	
212	Sierra Wireless	AC595	PC Card	
213	Sierra Wireless	AC597U	USB	
214	Sierra Wireless	AirCard580	PC Card	
215	SIMCOM	U6-T	USB	
216	SIMCOM	U9R-T	USB	

217	Solomon	D12LC	USB	
218	Solomon	S3GM-646	USB	
219	Solomon	S3GM-660	USB	
220	Solomon	S3GM-690	USB	
221	Solomon	SEGM-520C	USB	
222	Sony Ericsson	MD300	USB	
223	Sony Ericsson	PC300	PC Card	
224	Sprint	U598	USB	
225	Sprint	U760	USB	
226	Tactio	MD72U	USB	
227	TeleWell	TW-3G	ExpressCard	
228	Telit	UC864	USB	
229	UTStarcom	C6805	USB	
230	UTStarcom	Q6085(CU189)	USB	
231	UTStarcom	UM100	USB	
232	UTStarcom	UM150	USB	
233	UTStarcom	UM175	USB	
234	Verizon	ES720	USB	
235	Verizon	PC5750	PC Card	
236	Verizon	UM175	USB	
237	Vodafone	EasyBox	USB	
238	Vodafone	K4505	USB	
239	Vtion	E1916	USB	
240	Vtion	V1810	USB	
241	Webee	Modem Configuration	USB	
242	Yiso	C893	PC Card	
243	Zoom	4593	USB	
244	Zoom	72TRI	USB	
245	ZTE	K3520	USB	
246	ZTE	K-3565-Z	USB	
247	ZTE	MF100	USB	
248	ZTE	MF330	PC Card	
249	ZTE	MF332	PC Card	
250	ZTE	MF620	USB	
251	ZTE	MF622	USB	
252	ZTE	MF626	USB	
253	ZTE	MF627	USB	
254	ZTE	MF633	USB	
255	ZTE	MF636	USB	
256	ZTE	MF636 BP	USB	
257	ZTE	MF636+	USB	
258	ZTE	MF636-BKIC	USB	
259	ZTE	MF637	USB	
260	ZTE	MF668	USB	

261	ZTE	AC2726	USB	
262	ZTE	AC2736	USB	
263	ZTE	AC560	USB	
264	ZTE	AC580	USB	
265	ZTE	AC8710	USB	
266	ZTE	MC315+	PC Card	
267	ZTE	MV140B	USB	
268	ZTE	MF637U	USB	
269	ZTE	MU-318	USB	
270	ZTE	MU-350	USB	